

SAMPLE CUPS

RINSING PROCEDURES

Items Supplied

- 1 – Rinsing Canister (Retain for Future Use)
- 1 – Drain Lid/Solid Lid
- 2 – Bottles of Decontamination Solution
- 1 – Shipping Canister with Yellow Lid
- 1 – FedEx Ground Return Record

1. PREPARE


After completion of tests, empty sample cups from the instrument waste bin into the white rinsing canister.



LOAD

2. RINSE


Fill rinsing canister $\frac{1}{2}$ to $\frac{3}{4}$ full with D.I. water and add $\frac{1}{2}$ bottle of decontamination solution.



FILL

3. ROTATE

Seal canister with solid lid. Rotate canister 3 or 4 times ensuring all sample cups are exposed to the liquid and let stand for 5-10 minutes.



RINSE

DRAIN

4. DRAIN

Replace Solid Lid with Drain Lid and pour solution down drain. Inverting the container a second and third time will allow for additional liquid to be drained from sample cups.



DRAIN

5. STORE




Empty decontaminated sample cups into shipping container, place yellow lid on container and store in box. Repeat until shipping container is full.



Shipping Canister

6. SHIP

Once box is full, enclose a completed FedEx Ground pickup record and empty solution bottles. Seal box with reprinted return address on outside flap and call FedEx Ground at 1-800-937-4587 for pickup.



SHIP